

'Click' to download complete Manual



Learning ♦ Knowledge ♦ Performance



D009/D011/D012/D013 **SERVICE MANUAL**

003315MIU

LANIER RICOH SAVIN



**D009/D011/D012/D013
SERVICE MANUAL**

**LANIER
RICOH
SERIES**

service-repairmanual.com



RICOH UNIVERSITY

Learning ♦ Knowledge ♦ Performance

D009/D011/D012/D013 SERVICE MANUAL

003315MIU

LANIER RICOH SAVIN

It is the reader's responsibility when discussing the information contained within this document to maintain a level of confidentiality that is in the best interest of Ricoh Americas Corporation and its member companies.

NO PART OF THIS DOCUMENT MAY BE REPRODUCED IN ANY FASHION AND DISTRIBUTED WITHOUT THE PRIOR PERMISSION OF RICOH AMERICAS CORPORATION.

All product names, domain names or product illustrations, including desktop images, used in this document are trademarks, registered trademarks or the property of their respective companies.

They are used throughout this book in an informational or editorial fashion only and for the benefit of such companies. No such use, or the use of any trade name, or web site is intended to convey endorsement or other affiliation with Ricoh products.

WARNING

The Service Manual contains information regarding service techniques, procedures, processes and spare parts of office equipment distributed by Ricoh Americas Corporation. Users of this manual should be either service trained or certified by successfully completing a Ricoh Technical Training Program.

Untrained and uncertified users utilizing information contained in this service manual to repair or modify Ricoh equipment risk personal injury, damage to property or loss of warranty protection.

Ricoh Americas Corporation

LEGEND

PRODUCT CODE	COMPANY			
	GESTETNER	LANIER	RICOH	SAVIN
D009	MP 4000B	LD040B	Aficio MP 4000B	9040b
D011	MP 4000	LD040	Aficio MP 4000	9040
D012	MP 5000B	LD050B	Aficio MP 5000B	9050b
D013	MP5000	LD050	Aficio MP 5000	9050

DOCUMENTATION HISTORY

REV. NO.	DATE	COMMENTS
*	01/2008	Original Printing

D009/D011/D012/D013

TABLE OF CONTENTS

INSTALLATION

1. INSTALLATION.....	1-1
1.1 INSTALLATION REQUIREMENTS	1-1
1.1.1 ENVIRONMENT	1-2
1.1.2 MACHINE LEVEL.....	1-3
1.1.3 MINIMUM SPACE REQUIREMENTS	1-3
1.1.4 POWER REQUIREMENTS	1-4
1.2 INSTALLATION FLOW CHART	1-5
1.3 MAIN MACHINE INSTALLATION.....	1-6
1.3.1 ACCESSORY CHECK	1-6
1.3.2 INSTALLATION PROCEDURE	1-7
1.3.3 MOVING THE MACHINE	1-15
1.3.4 TRANSPORTING THE MACHINE	1-15
1.4 PAPER FEED UNIT INSTALLATION (D351)	1-16
1.4.1 ACCESSORY CHECK	1-16
1.4.2 INSTALLATION PROCEDURE	1-16
1.5 LCT 2000-SHEET (D352).....	1-19
1.5.1 ACCESSORY CHECK	1-19
1.5.2 INSTALLATION PROCEDURE	1-19
1.6 1200-SHEET LCT (D353).....	1-22
1.6.1 COMPONENT CHECK.....	1-22
1.6.2 INSTALLATION PROCEDURE	1-22
1.7 AUTO REVERSE DOCUMENT FEEDER (B802).....	1-25
1.7.1 COMPONENT CHECK.....	1-25
1.7.2 INSTALLATION PROCEDURE	1-25
1.8 PLATEN COVER INSTALLATION (G329)	1-30
1.9 1-BIN TRAY UNIT (D389).....	1-31
1.9.1 COMPONENT CHECK.....	1-31
1.9.2 INSTALLATION PROCEDURE	1-31
1.10 BRIDGE UNIT (D386).....	1-34
1.10.1 COMPONENT CHECK	1-34
1.10.2 INSTALLATION PROCEDURE.....	1-34

1.11	2000/3000-SHEET FINISHERS (B804/B805).....	1-38
1.11.1	ACCESSORY CHECK.....	1-38
1.11.2	INSTALLATION PROCEDURE.....	1-39
1.12	PUNCH UNIT (B702).....	1-44
1.12.1	COMPONENT CHECK.....	1-44
1.12.2	INSTALLATION PROCEDURE.....	1-45
1.13	1000-SHEET FINISHER (B408).....	1-49
1.13.1	ACCESSORY CHECK.....	1-49
1.13.2	INSTALLATION PROCEDURE.....	1-50
1.14	KEY COUNTER BRACKET.....	1-53
1.14.1	INSTALLATION PROCEDURE.....	1-53
1.15	KEY COUNTER INTERFACE UNIT.....	1-55
1.15.1	INSTALLATION PROCEDURE.....	1-55
1.16	ANTI-CONDENSATION HEATER (SCANNER).....	1-57
1.16.1	INSTALLATION PROCEDURE.....	1-57
1.17	TRAY HEATER.....	1-59
1.17.1	INSTALLATION PROCEDURE.....	1-59
1.18	TRAY HEATER (OPTIONAL PAPER FEED UNIT).....	1-61
1.18.1	COMPONENT CHECK.....	1-61
1.18.2	INSTALLATION PROCEDURE.....	1-61
1.19	HDD OPTION (D362, ONLY FOR D009/D012).....	1-69
1.19.1	COMPONENT CHECK.....	1-69
1.19.2	INSTALLATION PROCEDURE.....	1-70
1.20	DATAOVERWRITESECURITY UNIT TYPE I (D362).....	1-71
1.20.1	BEFORE YOU BEGIN THE PROCEDURE.....	1-71
1.20.2	SEAL CHECK AND REMOVAL.....	1-71
1.20.3	INSTALLATION PROCEDURE.....	1-72
1.21	COPY DATA SECURITY UNIT.....	1-75
1.21.1	INSTALLATION PROCEDURE.....	1-75
1.22	HDD ENCRYPTION UNIT.....	1-78
1.22.1	BEFORE YOU BEGIN THE PROCEDURE.....	1-78
1.22.2	SEAL CHECK AND REMOVAL.....	1-78
1.22.3	INSTALLATION PROCEDURE.....	1-79
1.22.4	RECOVERY FROM A DEVICE PROBLEM.....	1-80
1.23	BROWSER UNIT TYPE D.....	1-82
1.23.1	INSTALLATION PROCEDURE.....	1-82

PREVENTIVE MAINTENANCE

2. PREVENTIVE MAINTENANCE.....	2-1
2.1 PM TABLE - MAINFRAME	2-1
2.2 PM TABLE - OPTIONS.....	2-6

REPLACEMENT AND ADJUSTMENT

3. REPLACEMENT AND ADJUSTMENT	3-1
3.1 GENERAL CAUTIONS	3-1
3.1.1 LASER UNIT	3-1
3.1.2 USED TONER	3-1
3.2 SPECIAL TOOLS AND LUBRICANTS	3-2
3.2.1 SPECIAL TOOLS	3-2
3.2.2 LUBRICANTS.....	3-2
3.3 EXTERIOR COVERS	3-3
3.3.1 FRONT DOOR, UPPER AND LOWER INNER COVER.....	3-3
3.3.2 LEFT COVER	3-4
3.3.3 REAR COVER.....	3-4
3.3.4 RIGHT REAR COVER.....	3-4
3.3.5 OPERATION PANEL.....	3-5
3.3.6 PAPER EXIT COVER.....	3-6
3.3.7 INNER TRAY.....	3-7
3.4 SCANNER -1.....	3-8
3.4.1 EXPOSURE GLASS.....	3-8
3.4.2 ORIGINAL LENGTH/WIDTH SENSORS.....	3-8
3.4.3 EXPOSURE LAMP	3-10
3.4.4 SCANNER MOTOR.....	3-12
3.4.5 SENSOR BOARD UNIT (SBU).....	3-13
3.4.6 LAMP STABILIZER	3-14
3.4.7 SIO (SCANNER IN/OUT) BOARD.....	3-15
3.4.8 SCANNER HP SENSOR.....	3-15
3.4.9 PLATEN COVER SENSOR.....	3-16
3.5 SCANNER -2.....	3-17
3.5.1 FRONT SCANNER WIRE	3-17
3.5.2 REAR SCANNER WIRE.....	3-19

3.5.3 TOUCH PANEL POSITION ADJUSTMENT	3-22
3.6 LASER UNIT	3-23
3.6.1 CAUTION DECAL LOCATIONS.....	3-23
3.6.2 LASER UNIT	3-23
3.6.3 POLYGON MIRROR MOTOR.....	3-24
3.6.4 LASER SYNCHRONIZATION DETECTOR.....	3-25
3.6.5 LD UNIT	3-25
3.7 PCDU	3-28
3.7.1 PCDU (PHOTOCONDUCTOR AND DEVELOPMENT UNIT)	3-28
3.7.2 DRUM.....	3-28
3.7.3 PICK-OFF PAWLS	3-32
3.7.4 CHARGE ROLLER AND CLEANING ROLLER.....	3-33
3.7.5 DRUM CLEANING BLADE 2.....	3-34
3.7.6 DRUM CLEANING BLADE 1.....	3-34
3.7.7 ID SENSOR.....	3-35
3.8 DEVELOPMENT	3-36
3.8.1 DEVELOPMENT FILTER	3-36
3.8.2 DEVELOPMENT ROLLER	3-36
3.8.3 DEVELOPER.....	3-37
3.8.4 TD SENSOR.....	3-39
3.9 TRANSFER	3-40
3.9.1 TRANSFER BELT UNIT	3-40
3.9.2 TRANSFER BELT	3-40
3.9.3 TONER OVERFLOW SENSOR	3-43
3.9.4 TRANSFER BELT CLEANING BLADE	3-43
3.10 PAPER FEED	3-44
3.10.1 PAPER FEED UNIT	3-44
3.10.2 PICK-UP, FEED AND SEPARATION ROLLERS.....	3-44
3.10.3 TRAY LIFT MOTOR.....	3-45
3.10.4 RELAY, TRAY LIFT, PAPER END AND PAPER FEED SENSORS	3-45
3.10.5 REGISTRATION SENSOR.....	3-46
3.11 FUSING	3-48
3.11.1 FUSING UNIT	3-48
3.11.2 WEB ROLLER UNIT	3-48
3.11.3 BRAKE PAD	3-49
3.11.4 WEB HOLDER ROLLER AND WEB ROLLERS	3-50

3.11.5	PRESSURE ROLLER CLEANING ROLLER	3-53
3.11.6	THERMOSTAT	3-54
3.11.7	THERMISTOR	3-55
3.11.8	HOT ROLLER STRIPPERS.....	3-55
3.11.9	FUSING LAMPS	3-56
3.11.10	HOT ROLLER AND PRESSURE ROLLER.....	3-57
3.12	PAPER EXIT.....	3-59
3.12.1	PAPER EXIT UNIT	3-59
3.12.2	FUSING EXIT, PAPER OVERFLOW, AND PAPER EXIT SENSORS	3-59
3.12.3	JUNCTION JAM SENSOR.....	3-60
3.12.4	PAPER EXIT MOTOR	3-60
3.13	DUPLEX	3-62
3.13.1	DUPLEX UNIT	3-62
3.13.2	RIGHT DOOR COVER	3-64
3.13.3	DUPLEX DOOR SENSOR.....	3-64
3.13.4	DUPLEX ENTRANCE SENSOR.....	3-64
3.13.5	DUPLEX EXIT SENSOR.....	3-65
3.13.6	DUPLEX/BY-PASS MOTOR.....	3-67
3.13.7	DUPLEX INVERTER MOTOR	3-67
3.14	BY-PASS	3-70
3.14.1	BY-PASS PAPER SIZE SENSOR	3-70
3.14.2	BY-PASS PAPER END SENSOR.....	3-71
3.14.3	BY-PASS PICK-UP, FEED AND SEPARATION ROLLER, TORQUE LIMITER	3-71
3.14.4	BY-PASS FEED CLUTCH	3-72
3.15	DRIVE AREA	3-73
3.15.1	PAPER FEED CLUTCH.....	3-73
3.15.2	DEVELOPMENT PADDLE MOTOR	3-73
3.15.3	TRANSFER/DEVELOPMENT MOTOR	3-74
3.15.4	DRUM MOTOR.....	3-74
3.15.5	FUSING MOTOR	3-75
3.15.6	WEB MOTOR	3-75
3.15.7	PAPER FEED MOTOR.....	3-76
3.15.8	TRANSFER BELT CONTACT MOTOR.....	3-76
3.15.9	REGISTRATION MOTOR.....	3-76
3.15.10	TONER SUPPLY MOTOR	3-77

3.16	ELECTRICAL COMPONENTS	3-78
3.16.1	CONTROLLER UNIT	3-78
3.16.2	HDD UNIT (STANDARD FOR D011/D013)	3-78
3.16.3	CONTROLLER BOARD	3-79
3.16.4	MOTHER BOARD	3-81
3.16.5	BICU	3-82
3.16.6	IOB	3-82
3.16.7	PSU	3-83
3.16.8	HIGH VOLTAGE POWER SUPPLY BOARD	3-84
3.16.9	FUSING EXHAUST FAN	3-84
3.16.10	CONTROLLER FAN	3-85
3.17	COPY ADJUSTMENTS	3-86
3.17.1	OVERVIEW	3-86
3.17.2	PRINTING	3-86
3.17.3	SCANNING	3-90
3.17.4	ADF IMAGE ADJUSTMENT	3-92
3.17.5	TOUCH SCREEN CALIBRATION	3-92

TROUBLESHOOTING

4.	TROUBLESHOOTING	4-1
4.1	SERVICE CALL CONDITIONS	4-1
4.1.1	SUMMARY	4-1
4.1.2	SC CODE DESCRIPTIONS	4-2
4.2	SC TABLES: SC1XX	4-3
4.3	SC TABLES: SC2XX	4-7
4.4	SC TABLES: SC3XX	4-9
4.5	SC TABLES: SC4XX	4-12
4.6	SC TABLES: SC5XX -1	4-14
4.7	SC TABLES: SC5XX -2	4-19
4.8	SC TABLES: SC6XX	4-22
4.9	SC TABLES: SC7XX -1	4-28
4.10	SC TABLES: SC7XX -2	4-33
4.11	SC TABLES: SC8XX -1	4-36
4.12	SC TABLES: SC8XX -2	4-42
4.13	SC TABLES: SC9XX	4-48
4.14	ELECTRICAL COMPONENT DEFECTS	4-52

4.14.1	SENSORS	4-52
4.14.2	SWITCHES	4-56
4.15	BLOWN FUSE CONDITIONS.....	4-58

SERVICE TABLES

5.	SERVICE TABLES.....	5-1
5.1	SERVICE PROGRAM MODE.....	5-1
5.1.1	SERVICE PROGRAM MODE OPERATION.....	5-1
5.1.2	SERVICE PROGRAM MODE TABLES	5-2
5.2	SP1-XXX: FEED-1.....	5-3
5.3	SP1-XXX: FEED-2.....	5-11
5.4	SP1-XXX: FEED-3.....	5-16
5.5	SP2-XXX: DRUM-1.....	5-20
5.6	SP2-XXX: DRUM-2.....	5-28
5.7	SP2-XXX: DRUM-3.....	5-34
5.8	SP3-XXX: PROCESS-1.....	5-37
5.9	SP4-XXX: SCANNER-1.....	5-40
5.10	SP4-XXX: SCANNER-2	5-54
5.11	SP4-XXX: SCANNER-3	5-60
5.12	SP5-XXX: MODE-1.....	5-75
5.13	SP5-XXX: MODE-2.....	5-91
5.14	SP5-XXX: MODE-3.....	5-95
5.15	SP5-XXX: MODE-4.....	5-118
5.16	SP5-XXX: MODE-5.....	5-134
5.17	SP6-XXX: PERIPHERALS-1.....	5-142
5.18	SP7-XXX: DATA LOG-1	5-152
5.19	SP7-XXX: DATA LOG-2	5-160
5.20	SP8-XXX: DATA LOG2-1	5-170
5.21	SP8-XXX: DATA LOG2-2	5-180
5.22	SP8-XXX: DATA LOG2-3	5-189
5.23	SP8-XXX: DATA LOG2-4	5-199
5.24	SP8-XXX: DATA LOG2-5	5-209
5.25	INPUT CHECK - 1	5-216
5.25.1	COPIER	5-216
5.26	INPUT CHECK -2	5-222
5.26.1	OPTIONS.....	5-222

5.27	OUTPUT CHECK -1	5-227
5.27.1	COPIER	5-227
5.28	OUTPUT CHECK -2	5-233
5.28.1	1000-SHEET FINISHER (B408)	5-233
5.28.2	2000/3000-SHEET (BOOKLET) FINISHER	5-234
5.29	USING SP MODES.....	5-236
5.29.1	TEST PATTERN PRINTING	5-236
5.29.2	SMC PRINT OUT LISTS: SP5-990	5-237
5.29.3	NIP BAND WIDTH ADJUSTMENT: SP1-109	5-238
5.29.4	MEMORY CLEAR: SP5-801	5-239
5.29.5	SOFTWARE RESET	5-241
5.29.6	SYSTEM SETTINGS AND COPY SETTING RESET	5-241
5.29.7	COPIER SETTING RESET	5-242
5.30	UPDATING THE FIRMWARE.....	5-244
5.30.1	BEFORE YOU BEGIN	5-244
5.30.2	UPDATING FIRMWARE	5-244
5.30.3	HANDLING FIRMWARE UPDATE ERRORS	5-246
5.31	NVRAM DATA UPLOAD/DOWNLOAD.....	5-249
5.31.1	UPLOADING NVRAM DATA (SP5-824)	5-249
5.31.2	DOWNLOADING NVRAM DATA (SP5-825).....	5-249
5.32	SD CARD APPLI MOVE	5-250
5.32.1	OVERVIEW.....	5-250
5.32.2	MOVE EXEC.....	5-250
5.32.3	UNDO EXEC.....	5-251
5.33	SELF-DIAGNOSTIC MODE.....	5-252
5.33.1	SELF-DIAGNOSTIC MODE AT POWER ON	5-252
5.33.2	SELF-DIAGNOSTIC TEST FLOW	5-253
5.33.3	DETAILED SELF-DIAGNOSTIC MODE	5-253
5.33.4	EXECUTING DETAILED SELF-DIAGNOSIS.....	5-254
5.34	USING THE DEBUG LOG	5-255
5.34.1	OVERVIEW.....	5-255
5.34.2	SWITCHING ON AND SETTING UP SAVE DEBUG LOG	5-255
5.35	DIP SWITCHES	5-261
5.35.1	I/O BOARD: DIP SW101.....	5-261

DETAILED SECTION DESCRIPTIONS

6. DETAILED SECTION DESCRIPTIONS	6-1
6.1 OVERVIEW	6-1
6.1.1 COMPONENT LAYOUT	6-1
6.2 BOARD STRUCTURE.....	6-5
6.2.1 BLOCK DIAGRAM.....	6-5
6.3 COPY PROCESS.....	6-9
6.3.1 OVERVIEW	6-9
6.4 SCANNING.....	6-11
6.4.1 OVERVIEW	6-11
6.4.2 SCANNER DRIVE	6-12
6.4.3 ORIGINAL SIZE DETECTION IN PLATEN MODE.....	6-13
6.5 IMAGE PROCESSING	6-15
6.5.1 OVERVIEW	6-15
6.5.2 SBU (SENSOR BOARD UNIT).....	6-16
6.5.3 AUTO IMAGE DENSITY (ADS).....	6-18
6.5.4 IPU (IMAGE PROCESSING UNIT)	6-19
6.5.5 IMAGE PROCESSING MODES	6-19
6.5.6 SUMMARY OF IMAGE PROCESSING FUNCTIONS	6-19
6.5.7 IMAGE PROCESSING STEPS	6-20
6.5.8 INDEPENDENT DOT ERASE	6-21
6.6 LASER EXPOSURE	6-23
6.6.1 OVERVIEW	6-23
6.6.2 AUTO POWER CONTROL (APC).....	6-24
6.6.3 LD SAFETY SWITCHES	6-24
6.7 AROUND THE DRUM	6-25
6.7.1 OVERVIEW	6-25
6.7.2 DRUM CLEANING	6-26
6.7.3 DRIVE MECHANISM.....	6-27
6.7.4 DRUM PAWLS	6-27
6.8 DRUM CHARGE.....	6-28
6.8.1 OVERVIEW	6-28
6.8.2 CHARGE ROLLER VOLTAGE CORRECTION	6-29
6.8.3 ID SENSOR PATTERN PRODUCTION TIMING.....	6-31
6.8.4 DRUM CHARGE ROLLER CLEANING	6-31
6.9 DEVELOPMENT	6-32

6.9.1 OVERVIEW	6-32
6.9.2 DRIVE MECHANISM.....	6-33
6.9.3 DEVELOPER MIXING.....	6-33
6.9.4 DEVELOPMENT BIAS	6-34
6.9.5 TONER SUPPLY	6-36
6.9.6 TONER NEAR END/END DETECTION	6-38
6.9.7 TONER END RECOVERY	6-39
6.9.8 TONER SUPPLY WITH ABNORMAL SENSORS	6-39
6.10 DRUM CLEANING AND TONER RECYCLING	6-40
6.10.1 DRUM CLEANING.....	6-40
6.10.2 TONER RECYCLING	6-41
6.11 PAPER FEED	6-42
6.11.1 OVERVIEW.....	6-42
6.11.2 PAPER FEED DRIVE	6-43
6.11.3 PICK-UP AND SEPARATION ROLLER RELEASE MECHANISM.....	6-43
6.11.4 PAPER LIFT	6-44
6.11.5 TRAY LOCK MECHANISM.....	6-45
6.11.6 PAPER SIZE DETECTION – TRAYS 1 AND 2.....	6-46
6.11.7 PAPER END DETECTION – TRAYS 1 AND 2	6-47
6.11.8 REGISTRATION	6-48
6.12 BY-PASS TRAY.....	6-49
6.12.1 OVERVIEW.....	6-49
6.12.2 DRIVE.....	6-49
6.12.3 BY-PASS PAPER SEPARATION	6-50
6.12.4 BY-PASS PAPER SIZE DETECTION.....	6-50
6.13 DUPLEX UNIT	6-51
6.13.1 OVERVIEW.....	6-51
6.13.2 DUPLEX DRIVE.....	6-52
6.13.3 INVERTER MECHANISM	6-53
6.13.4 DUPLEX OPERATION	6-54
6.14 IMAGE TRANSFER AND PAPER SEPARATION	6-56
6.14.1 OVERVIEW.....	6-56
6.14.2 BELT DRIVE MECHANISM	6-57
6.14.3 TRANSFER BELT UNIT CONTACT MECHANISM	6-57
6.14.4 IMAGE TRANSFER AND PAPER SEPARATION MECHANISM.....	6-58
6.14.5 TRANSFER BELT CHARGE	6-59
6.14.6 TRANSFER BELT CLEANING MECHANISM.....	6-61

6.15	IMAGE FUSING	6-62
6.15.1	OVERVIEW	6-62
6.15.2	FUSING DRIVE	6-63
6.15.3	PRESSURE RELEASE MECHANISM	6-63
6.15.4	FUSING ENTRANCE GUIDE SHIFT MECHANISM	6-64
6.15.5	PRESSURE ROLLER CLEANING	6-64
6.15.6	HOT ROLLER CLEANING	6-65
6.15.7	HOT ROLLER STRIPPER CLEANING	6-66
6.15.8	FUSING TEMPERATURE CONTROL	6-69
6.15.9	CPM DOWN SYSTEM	6-71
6.15.10	PAPER FEED WAITING MODE	6-72
6.15.11	OVERHEAT PROTECTION	6-72
6.16	PAPER EXIT	6-73
6.16.1	OVERVIEW	6-73
6.16.2	JUNCTION GATE MECHANISM	6-74
6.16.3	EXIT GUIDE PLATE AND DE-CURLER ROLLERS	6-76
6.17	ENERGY SAVER MODES	6-77
6.17.1	OVERVIEW	6-77
6.17.2	ENERGY SAVER MODE	6-78
6.17.3	AUTO OFF MODE	6-78
6.18	MFP OPTIONS	6-80
6.18.1	COPY DATA SECURITY UNIT	6-80
6.18.2	FILE FORMAT CONVERTER (M13)	6-81
6.18.3	DATA OVERWRITE SECURITY UNIT (D362)	6-81
6.18.4	HDD ENCRYPTION UNIT (D377)	6-83

SPECIFICATIONS

7.	SPECIFICATIONS	7-1
7.1	GENERAL SPECIFICATIONS	7-1
7.1.1	GENERAL	7-1
7.1.2	POWER CONSUMPTION	7-3
7.2	MACHINE CONFIGURATION	7-5
7.2.1	COPIER	7-5
7.3	OPTIONAL EQUIPMENT -1	7-8
7.3.1	ARDF	7-8
7.3.2	TWO-TRAY PAPER FEED UNIT	7-8

7.3.3 LCT 2000-SHEET	7-9
7.3.4 LCT 1200-SHEET	7-9
7.3.5 1-BIN TRAY UNIT	7-10
7.3.6 BRIDGE UNIT	7-10
7.3.7 1000-SHEET FINISHER.....	7-11
7.4 OPTIONAL EQUIPMENT -2	7-13
7.4.1 3000-SHEET FINISHER.....	7-13
7.4.2 2000-SHEET BOOKLET FINISHER.....	7-14
7.4.3 PUNCH UNIT FOR 2000/3000-SHEET (BOOKLET) FINISHER	7-17

B408 1000-SHEET FINISHER SR790

SEE SECTION B408 FOR DETAILED TABLE OF CONTENTS

B802 AUTO REVERSE DOCUMENT FEEDER DF3010

SEE SECTION B802 FOR DETAILED TABLE OF CONTENTS

B804/B805 BOOKLET FINISHER SR3020/FINISHER SR3030

SEE SECTION B804/B805 FOR DETAILED TABLE OF CONTENTS

B838 SCANNER ACCESSIBILITY OPTION TYPE 4045

SEE SECTION B838 FOR DETAILED TABLE OF CONTENTS

D346 FAX OPTION TYPE 5000

SEE SECTION D346 FOR DETAILED TABLE OF CONTENTS

D351 PAPER FEED UNIT PB3040

SEE SECTION D351 FOR DETAILED TABLE OF CONTENTS

D352 LCT PB3050

SEE SECTION D352 FOR DETAILED TABLE OF CONTENTS

D353 1200-SHEET LCIT RT3000

SEE SECTION D353 FOR DETAILED TABLE OF CONTENTS

D381 PRINTER/SCANNER OPTION TYPE 5000

SEE SECTION D381 FOR DETAILED TABLE OF CONTENTS

D386 BRIDGE UNIT BU3030

SEE SECTION D386 FOR DETAILED TABLE OF CONTENTS

D389 1-BIN TRAY BN3040

SEE SECTION D389 FOR DETAILED TABLE OF CONTENTS

service-repairmanual.com